



evO WHITE

evO WHITE

evO SILVER

evO SILVER

evO BLACK

evO BLACK

ecO pure

Intellicig Cartridges

If you experience any liquid leaking from the cartridge, your mouth, please remove the cartridge and use a paper clip or similar item to push through the tiny hole in the mouthpiece and remove the inner capsule. Wipe the outside of this capsule and the inside of the mouthpiece with a piece of absorbent paper. Replace the capsule and ensure that it is seated into the bottom of the mouthpiece.

Draining the vaporiser once a day can help to avoid this problem.

Main Parts Of The Intellicig



USB Charger



Mains USB Plug



Intellicig UK Telephone number : 0845 527 6115

From Europe: +44 (0) 845 527 6115

Toll Free from USA Only : 866 634 1022

Email info@intellicig.com www.intellicig.com

Intellicig User Guide

When you receive your Intellicig, remove the blank cartridge attached to the vapour device and replace it with a new cartridge from the 4 pack you should have received with the kit.

Batteries are pre-charged which means they should be ready to use straight out of the box.

Always keep your Intellicig clean as described in the maintenance section of this manual.

When charging your battery, please allow 3 hours for the unit to be fully charged. When the battery is fully charged the light on the USB charger should alternate from red to green slowly. Also, the LED on the battery may illuminate continuously when fully charged.

Important Things To Remember

Store cartridges, ECOpure Liquid and your Intellicig away from children
Never use your Intellicig with a dry cartridge, this can result in damage to your vaporiser

If the vaporiser is activated for 5 seconds, your Intellicig will cut off for 2 minutes, this is a safety measure to prevent the vaporiser overheating.

Always dispose of your empty cartridges and bottles with care

Intellicig is intended for use by adults ONLY.

Do not use your Intellicig more than you would normally use a cigarette

Draining Your Intellicig Vaporiser

Cleaning your vaporiser is vital and should be done regularly.

This will result in better vapour, cleaner taste and better battery connection.

To clean your vaporiser you will need some absorbent paper.

Blow out excess liquid from the vaporiser by removing the cartridge and battery, cleaning the end of the vaporiser then blowing into the battery side of the vaporiser, as if blowing a whistle, whilst holding the vaporiser from the cartridge side with the paper. The paper will collect any liquid that is present in the vaporiser. Repeat this process until no liquid is visible.

See diagram below.



Cleaning The Battery & Vaporiser Contacts

Cleaning improves performance of your Intellicig. Absorbent paper is a good material to use for this task.

Remove the battery from the vaporiser and clean the part of the battery that screws into the vaporiser. You can do this by taking hold of this part with the paper in your hand and turning the battery. This will remove any deposits from the battery and transfer it to the paper.

Repeat this until the metal contacts are clean.

To clean the vaporiser contacts, place a piece of paper inside the part that screws onto the battery and twist it round and round until it is clean.

Please note that this technique also works for cleaning the USB charger



Refilling Cartridges With ECOpure

Use a piece of absorbent paper to work on. Remove the cartridge and use a paper clip or similar item to push through the tiny hole in the mouthpiece and remove the inner capsule. Carefully remove the fibre filling from the capsule and refill it to approximately 75% (3/4) full. Replace the filling ensuring it is level with the top of the capsule. Ensure the outside of the capsule and the inside of the mouthpiece are dry and replace the capsule into the mouthpiece. Replace the cartridge on to the vaporiser and use as normal.